

בקר טמפרטורה ולחות



- Long press UP 1 button for 3 seconds, ① display flashes, press UP 1 or DOWN 1 button to set the start temperature(20°C default)

- Long press DOWN 1 button for 3 seconds ① the display flashes, press UP 1 or DOWN 1 button to set the stop temperature (30°C default)

Long press UP 2 button for 3 seconds, ② display flashes, press UP 2 or DOWN 2 button to set the start humidity(40%RH default)

Long press DOWN 2 button for 3 seconds, ② the display flashes, press UP 2 or DOWN 2 button to set the stop humidity (60%RH default)

.Long press DOWN 1 and DOWN 2 button for 3 seconds to reset the controller

Long press UP 1 and DOWN 1 to calibrate the temperature, -10~10 °C

Long press UP 2 and DOWN 2 to calibrate the humidity

